

# Topcon Digi-Star Junction Box

## Weighing



Proven signal summing solution designed for agricultural weighing systems

**Connects 2-4 load cells in parallel**

**Compatible with all Digi-Star scale systems**

**Technical Features:**

- Two-piece connectors allow for easier assembly and troubleshooting
- Polarized to ensure easy and proper connection
- Retention latches to hold the plug and header securely in place
- Available with a variety of J-Box cable lengths (4 – 90 feet)

### Reliable Load Cell Connector

The Topcon Digi-Star Junction Box (aka J-Box) connects multiple load cells in a scale system and is necessary to provide the weight signal displayed through an indicator or console. Designed rugged, its proven to withstand the harsh conditions of mobile weighing in agriculture.



**Two-Piece Connectors**

Easy assembly and troubleshooting

**Ruggedized Casing**

Proven in harsh agriculture conditions

New P/N	Description	Interchangeable with
411179	ASSY J-BOX 3PT-4PT PULLOFF	404254 - ASSY J-BOX 3PT/4PT MOBILE
1070262-01	KIT-JBOX 3PT-4PT PULLOFF 15FT CBL	404274 - KIT-J-BOX 3PT/4PT-15FT CBL

