

# Topcon RL-HV2S

Multi-Purpose Construction Laser



Ideal solution for horizontal,  
single slope, dual slope, or  
vertical applications

Learn more at [topconpositioning.com](https://www.topconpositioning.com)

 **TOPCON**

# Single-Slope Construction Laser

## Multi-use applications

Designed for a variety of tasks, it can be used for horizontal, sloping and vertical laser applications. Slopes up to  $\pm 5\%$  ( $\pm 15\%$  with tilting plate) can be used in either the X or Y axis. Turn it on its side and use it for layout and alignment jobs.

## High powered

With a working range over 1,300 feet or 400 meters (radius) the RL-HV2S has the power to cover even the biggest projects.

## Long battery life

Contractors who want a laser with a long battery life will love the RL-HV2S. With an operating time of 120 hours on alkaline batteries or 65 hours with the rechargeable Ni-MH battery pack, this laser will still be working long after others have quit.

## All weather dependability

With the IP66 rating, the RL-HV2S is "jobsite tough" and can withstand dust, a sudden shower, and even torrential rainfall.

## Bluetooth Laser Manager

Compatibility for iOS and Android provides wireless remote control using a cell phone to adjust slope and check calibration. No special remote control needed.

- » Long-range operation  
2,600 feet / 800 meters diameter
- » Horizontal, multi-slope  
and vertical applications
- » Up to 120 hours battery life
- » Tough IP66 construction rating
- » Laser Manager app (iOS and Android)

## Key Components

- RL-HV2 laser
- Laser manager app
- LS-80L height sensor included
- Bluetooth
- Sensor holder
- Batteries
- Carry case

## Five-year guarantee

The RL-HV2S laser comes with a five-year guarantee. Topcon backs up this reliable, accurate laser with the best factory warranty in the industry.